

1. **Preparation**;

- Read the instruction manual carefully before using the machine, and follow the instructions carefully.
- The machine should be used in a dry and well-ventilated area.
- Do not use the machine near flammable or explosive materials.
- Do not use the machine if you are tired or under the influence of alcohol or drugs.
- The machine should be used in accordance with the ON / OFF button; do not use the machine if the button is not working.
- The machine should be used in accordance with the instructions; do not use the machine if the instructions are not followed.

2. **Technical specifications**

Power	220 - 240V, 50 Hz
Power consumption	1000 W
Capacity	(38) L
Volume	40 L / S
Pressure	13 KPA
Weight	3.0 M

3. **ACCESSORIES**

- 175 X 48mm tube
- 2 tubes
- 1 tube
- 1 tube
- 1 tube

4. **Notes**

- The machine should be used in accordance with the instructions; do not use the machine if the instructions are not followed.

Production Process

Injection Moulding Machine



Assembly Line



Parts of Testing Equipments



Raw Material Warehouse &
Finished Product Warehouse



Our Team

Activity, Cooperation, Home



Welcome to
contact US!

